



AQUA COOLER PTY LTD
161 ORCHARD ROAD
CHESTER HILL NSW 2162
Ph: (02) 9721 9333 Fax: (02) 9721 9344
www.aquacooler.com.au

AQUA COOLER OWNER'S MANUAL
IBWR

INSTALLER:

To ensure you install the unit easily and correctly, PLEASE READ THE FOLLOWING INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION. CHECK YOUR INSTALLATION FOR COMPLIANCE WITH PLUMBING, ELECTRICAL AND OTHER APPLICABLE CODES.

IMPORTANT:

All service is to be performed by an authorised service person.

WARNING - Warranty is voided if installation is not made in accordance with current Aqua Cooler instructions.

INSTALLATION:

1. Fit unit to wall recess.
2. Bolt angle at rear of the unit to either the sides or the rear recess.

Unit is almost free standing and requires minimal fixing.

Once plumbing is connected the unit is generally quite stable.

3. Connect mains water line to cooling inlet (either 3/8" female BSP or 1/2" male BSP).
4. Fit pressure reducing valve if supply is greater than 700kPa.
5. Connect drain.
6. Connect electrically.